



Twister Switch

	Cable	Black	Red	Yellow	Blue	Green
Satellite Twister	short	P005-40	P005-41	P005-42	P005-43	P005-44
Twister Bended Tube	long	P005-50	P005-51	P005-52	P005-53	P005-54
	short	P005-60	P005-61	P005-62	P005-63	P005-64
Twister Basic	long	P005-70	P005-71	P005-72	P005-73	P005-74
	short	P005-15	P005-16	P005-17	P005-18	P005-19
Twister Button	long	P005-75	P005-76	P005-77	P005-78	P005-79
	short	P005-85	P005-86	P005-87	P005-88	P005-89
Twister GooseNeck	long	P018-20	P018-21	P018-22	P018-23	P018-24

Contact & Product

mo-Vis BVBA

Biebuyckstraat 15 D
9850 Deinze - Belgium

Website: www.mo-vis.com

E-mail: contact@mo-vis.com

Telephone: +32 9 335 28 60



User & Installation manual

Produced and published by mo-Vis bvba, Belgium

Edition 1.5, February 2019

Manual item: D-P005-50-70-05

About the Twister

The Twister is a durable and reliable single switch that requires only the slightest touch on its 17 mm (0,65 in) surface for activation and is available in 5 colours. Twister uses the standard 3,5 mm mono jack. Simply plug Twister into the 3,5 mm female jack on a switch-adapted device, joystick or computer. (for computer you need a switch interface)

Operating the Twister

The Twister switch is a single mechanical 'normal open' switch. This means it will activate when pressed down.

To activate your Twister, simply press anywhere on the top of the activation surface. You will feel and hear a clear and audible "click".

Cleaning and maintenance

To keep Twister functioning properly

- Disconnect Twister and wipe clean with a cloth slightly dampened with water and a detergent or alcohol.
- Never immerse Twister in water or cleaning solution.
- Do not pull or wrap the cable around Twister.
- Do not attempt to open or disassemble the Twister enclosure.

Warranty & Customer Support Info

Your Twister switch includes a two-year limited warranty from mo-Vis. The warranty begins on the date of purchase and protects you against defects in materials and workmanship.

For support and to learn more about other products from mo-Vis, contact your authorised dealer or mo-Vis.

Installation options



CAUTION

Mind to not damage any cable while installing Twister.

When in use, regularly check cables.

Twister button


The Twister basic is mounted in a plastic holder with a diameter of 30 mm. The Twister button is delivered with a set of easy-to-install and durable mounting pieces. (see mounting page 4)



Twister on bended tube

The Twister is attached to a mo-Vis Quick-to-mount bended tube of 10 cm (3,94 in) and 6 mm (0,236 in) diameter.

Twister on bended tube can be mounted using the Quick-to-mount clamps to attach to other rods or wheelchair.



Satellite Twister

The Twister is equipped with an insert to mount on the All-round Joystick.



Twister Basic

The Twister basic can be mounted on a plate of metal/plastic with 2 screws or can be integrated in a tray or other flat surface.



Twister GooseNeck

The Twister basic is mounted on a gooseneck of 400 mm and comes with a cable length of 1500 mm.



Technical specifications

Twister switch technical specifications:

- Switch type: mechanical 'Normal Open'
- Connection type: wired
- Activation type: pressure
- Activation surface diameter: 1.7 cm (0.65 in)
- Activating force: 30 g (1.06 oz.)
- Travel before activation: 0.5 mm (0.02 in)
- Feedback: auditory click, tactile
- Plug size: 3.5 mm (1/8 in) mono jack
- Cable length: short cable 30 cm (11.81 in) or long cable 150 cm (70.86 in)

Mounting specifications

Mounting Twister Button

- Set 3M Dual Lock self-adhesive reclosable fasteners 25*2 mm (0.866 in*0.078 in)
- 1 self-adhesive rubber pad 28*2 mm (1.102 in*0.078 in)
- Set of 4 self-tapping screws (M2.2) : 2 screws with a diameter of 2.2 mm and a length of 6.5 mm and 2 of 9.5 mm length. The 2 additional screw holes in the base plate are reinforced to attach the button firmly on a flat surface.



Mounting Twister on bended tube:

- Diameter bended tube 6 mm (0.236 in)
- Length bended tube 10 cm (3.94 in)
- 1 quick to mount clamp of 6 mm (0.236 in)

Mounting Twister Basic:

- can be mounted on a hard, flat surface with 2 screws
- Hole diameter 2.5 mm (0.098 in)
- Distance 8 mm (0.315 in)
- 2 Types of screws delivered:
 - Diameter 2.2 mm (0.087 in)
Length 6.5 mm (0,266 in) for sheet thickness 0.5 mm (0.02 in) to 2 mm (0.079 in)
 - Diameter 2.2 mm (0.087 in)
Length 9.5 mm (0.374 in) for sheet thickness 3 mm (0.118 in) to 4.5 mm (0.177 in)

Mounting Satellite Twister:

- Diameter bended tube: 6 mm (0.236 in)
- Length bended tube: 10 cm (3.94 in)
- 1 satellite insert to mount on an All-round joystick

Mounting Twister GooseNeck:

- Can easily be mounted with the mo-Vis 8 mm clamp, whether or not combined with the rods and clamps of the mo-Vis Q2M system or other mounting system.
- The gooseneck base fits perfectly in the Universal Clamp (M007-01) and makes mounting on wheelchair tubes simple and easy.